


ASSEMBLY INSTRUCTIONS

Portable assembly



Evans Swing Arm Sconce

Item # RL 2010

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver	Slotted Screwdriver	Drill
Hammer	Pencil	Scissors

1. Carefully remove all parts from the box. Place on a clean, soft surface.
 2. Remove mounting plate (B) from fixture (E) by removing screws (D).
 3. Using the mounting plate (B) as a guide, mark anchor positions.
 4. Using a drill bit slightly smaller than the anchor, drill holes in the marked positions. Install anchors (A) into holes using hammer.
 5. Secure wood screws (C) to anchors (A), leaving 1/8" of exposed thread in order to hang fixture.
 6. Install mounting plate (B) to fixture (E) by securing with screws (D).
 7. Hang fixture (E) to wood screws (C).
 8. Thread cord covers (L1), (L2), & (L3) to fixture (E).
 9. Remove shade (I) from packaging and install to socket cup (G) using socket ring (H).
- NOTE:** If shade has additional packaging, carefully cut off from interior of shade to avoid damages.
10. Install light bulb into the socket.
 11. Swing the arm (N) to desired angle.
 12. Remove protective cover (M) from plug.
 13. Plug into electrical outlet and test the fixture.


Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

RALPH LAUREN



ASSEMBLY INSTRUCTIONS

Hardwire assembly



Evans Swing Arm Sconce

Item # RL 2010

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

TOOLS REQUIRED (NOT INCLUDED):

Phillips Screwdriver Slotted Screwdriver Scissors


1. Carefully remove all parts from the box. Place on a clean, soft surface.
2. Remove mounting plate (B) from fixture (E) by removing screws (D).
3. Install mounting plate (B) to the junction box and secure with mounting screws (P).
4. Remove portable cord and cord covers by removing CE-2 wire connector.
5. Insert direct wire plug (F) to the bottom of fixture (E).
6. Wrap fixture ground wire (bare copper) around the green grounding screw (see diagram 1). Tighten. Continue fixture ground wire and connect to supply ground wire (usually green or bare copper) using wire nut (O).
- NOTE:** It is imperative that the fixture is grounded.
7. Connect fixture neutral wire (white) to the supply neutral wire (usually white) using wire nut (O).
8. Connect the fixture hot wire (black) to the supply hot wire (usually black) using the wire nut (O).
- CAUTION:** Do not reverse the hot and neutral connections.
9. Make sure all wire connections are tight, then carefully tuck into the junction box.
10. Install fixture (E) to mounting plate (B) by securing with screws (D).

RALPH LAUREN



ASSEMBLY INSTRUCTIONS

Hardwire assembly



Evans Swing Arm Sconce

Item # RL 2010

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

11. Remove shade **(I)** from packaging and install to socket cup **(G)** using socket ring **(H)**.

NOTE: If shade has additional packaging, carefully cut off from interior of shade to avoid damages.

12. Install light bulb into the socket.

13. Swing the arm **(N)** to desired angle.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.

RALPH LAUREN

