


ASSEMBLY INSTRUCTIONS



Cranston Large Sconce


Item # S 2406

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

1. Carefully remove all parts from the box.
2. Remove the mounting plate (B) from the backplate (E) by loosening the side screws (D).
3. Affix mounting plate (B) to the outlet box and secure with mounting screws (C).
4. Drill a hole on the wall and make sure the distance will match to the fixture exactly.
5. Attach anchor (L) onto the wall hole.
6. Install the screw (K) into the anchor (L).
7. Connect the hot wire (BLACK) from the fixture to the hot wire from the outlet box (usually BLACK). Fasten them together with a plastic wire connector (A) provided and wrap the connection with electrical tape.
8. Repeat this procedure for the neutral wire (WHITE) from the fixture to the neutral wire from the outlet box (usually WHITE).
DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OR SAFETY WILL BE COMPROMISED.
9. Connect ground wire from the fixture (bare copper) to ground wire from the outlet box (usually green or copper in color).
IT IS IMPERATIVE THAT THIS FIXTURE BE GROUNDED.
10. Hang the bottom plate (J) onto screw (K).
11. Attach the backplate (E) to the mounting plate (B) and secure with side screws (D).
12. Put the harp (F) to the saddle.
13. Insert bulb (not included) into the socket.

ASSEMBLY INSTRUCTIONS



Cranston Large Sconce

Item # S 2406

NOTICE:

This light fixture should be installed in accordance with all applicable, local installation codes, and by a person familiar with the construction and operation of it, as well as the hazards involved. Inspect item and contents carefully. If any damage or defect is found, do not install. Retain all packaging material until installation is complete and approved.

14. Place shade (H) to the harp (F) and secure with finial (I).
15. Installation is complete, turn on power at fuse or circuit breaker.

Care Instructions: Clean only with a soft dry cloth or feather duster. Do not use abrasive or chemical agents.